

Water Curtain Cabinet Maintenance Guide

Symptoms	Causation	Troubles Shooting
Pump doesn't work	No power supply	Check the socket and the power cord, make sure that there is power supply.
	Miniature circuit breaker switched off	Switch on the miniature circuit breaker.
	Voltage is too low	Measure if the voltage is located within 220V \pm 8%; If not, equip with a regulator n.
	Pump is damaged.	Change a new adaptor and connect the power supply.
	Emergency Stop Button is power off	Turn the Emergency Stop Button clockwise, and it will be powered on.
	No water in tank	Fill the tank with water.
	Overheated protection	The machine will stop working while motor temperature is over 50°C. Start the machine again after it has been cooled down.
Air blower doesn't work	No power supply	Check the socket and the power cord, make sure that there is power supply.
	Miniature circuit breaker switched off	Switch on the miniature circuit breaker.
	Voltage is too low	Measure if the voltage is located within 220V \pm 8%; If not, equip with a regulator n.
	Pump is damaged.	Change a new adaptor and connect the power supply.
	Emergency Stop Button is power off	Turn the Emergency Stop Button clockwise, and it will be powered on.
	Air filter is blocked	Air filter is clogged with paint, need to replace with a new one.

⚠ All maintenance work must be done after both machine halt and power supply disconnected. NO maintenance without disconnect power supply or during working.